

Power Meter Monitor

**Business and Mission-**

**Critical Solutions Provider** 

**BACnet - Modbus Protocol Gateway** 





Model: PMM0408 Document: Data Sheet Document version: 1.0 Date: December 2022



#### **COPYRIGHT NOTICE**

The information in this document is subject to change without prior notice to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

#### **TRADEMARKS**

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

AMI is a trademark of American Megatrends Inc.

Intel & Atom are trademarks of Intel Corporation

IBM, PC/AT, PS/2&VGA are trademarks of International Business Machines Corporation Microsoft Windows is a trademark of Microsoft Corp. RTL is the trademark of Realtek Semiconductor Co., Ltd.

#### **DECLARATION OF CONFORMITY**

This restriction is subject to protect the operational process of the system in the business environment, which will produce, use, and transmit radiofrequency energy. Harmful interference to radio communication could result if instructions to the correct installation and usage were not applied. The interference prevention cannot be guaranteed even with proper installation according to the manual. If the device causes a bad effect on the radio / TV signal. The user could preclude that by turning the device on/off.

When this device produces some harmful interference, the user can use the following measure to solve the interference problem:

1-Setting the receiving antenna's direction or location to increase the distance between this device and receiver.

2-Plug in the device's power connector into different circuits of the power outlet with the receiver.

3-If any technical support is needed, the dealer or experienced radio/TV technical personnel must be informed.

#### TECHNICAL SUPPORT AND SERVICE

Visit <u>Pmm-usa.us</u> to browse FAQs and get further details. User should collect the following information before submitting technical support and service requests:

- Product name, model, and serial number.
- Installed software (operating system, OS version, installed applications and so on).
- Full description of the problem

-Detailed information about every error.

#### SAFETY INSTRUCTIONS

- Only trained and qualified personnel can install, operate, or maintain the device.
- Before starting the installation, all safety precautions must be read, and warning labels affixed to the device must be observed. Doing so protects the device from damage and ensures your safety.
- Safety precautions provided in this document may not cover all safety aspects, note to always remain mindful of safety.
- PMM is not liable for any consequence that results from violation of regulations pertaining to safe operations or safety codes pertaining to design, production, and equipment usage.
- DO NOT use liquids or decontamination spray to clean the device surface and assure that it is totally disconnected while cleaning.
- Take all measures to prevent device drop before or during installation.
- Prior to connecting the device to power source, ensure the source and device voltage and power are 100% matched.
- Keep the cables in a suitable covered place.
- If the device is not used for a long time, shut off the power to avoid the damages by transient overvoltage.
- DO NOT allow any liquid flow into the device; to avoid fire or short circuit.
- The recommended storage temperature range should NOT be less than 30°C OR higher than 85°C.

# \Lambda Warning:

- Read the power source and device inlet carefully.
- Handle device with both hands.
- Clean and maintain the device using recommended, safe, and suitable methods.

# Caution:

If any unauthorized changes of settings or repairs are done without PMM approval; then user's rights of controlling this device will be canceled.

# Contents

Ø

Q

# PAGE

KEY FEATURES	
DESCRIPTION	
SOFTWARE SPECIFICATIONS	5
HARDWARE SPECIFICATIONS	5
ORDERING INFORMATION	
BACnet to MODBUS CONVERTER INTERFACE	
login	
Set General Information and Web Page Theme	
Change password	
Overview	
Monitoring:	
Basic Settings	
Basic Settings	
General Server Configuration	
Network Settings	
Serial Settings	
Protocol Settings	
Modbus TCP Client (Master) Settings	
Modbus RTU/ASCII Master Settings	
BACnet IP Server Settings	
BACnet IP Client Settings	
BACnet MSTP Server	
BACnet MSTP Client	
BACnet PTP Server	
BACnet PTP Client	
Quick Settings	
Logging Timer	25
Tags Settings	
About	
Sign Out	

# **KEY FEATURES**

- Protocol conversion between Modbus RTU/ASCII/TCP and BACnet/IP
- Supports Modbus RTU/ASCII/TCP master/client
- Supports BACnet/IP server
- Connects up to 62 Modbus RTU/ASCII slaves
- Connects up to 32 Modbus TCP servers
- Easy and smooth configuration via webbased server
- Embedded traffic monitoring as well as diagnostic information for fast trouble shooting
- Optional 1 or 2 Ethernet 10/100 ports
- Optional supports 2.4/5 GHz WIFI
- Optional 2x customized Fiber optic ports
- 2 or 4 RS485 RS232 Serial communication ports (Customizable)
- Baud rate: 110-256000 bps
- Different Power supply options with over voltage and reverse polarity protection
- Operating temperature: -40 to 75°C (-40 to 167°F)
- Storage temperature: -40 to 85°C (-40 to 185°F)
- Ambient relative humidity 5 to 95% (noncondensing)
- EMI, EMS, EMC and shock protected
- Enclosure Ingress Protection Code: IP54

# DESCRIPTION

PMM0408 is a highly configurable industrial Ethernet gateway device which is capable of performing protocol conversion between Modbus RTU/ASCII/TCP and BACnet/IP.

PMM0408 provides the flexibility needed to fulfill the various conditions that arise with field devices that use different communication protocols to connect to the SCADA system.

PMM0408 gateways support a system log that main function is to record events so it can be easily monitored; users can easily review log data remotely through the web interface. The gateways also support status monitoring and fault protection functions. The status monitoring function notifies the SCADA system when a device gets disconnected or does not respond or faces any error or failures, in such cases the SCADA system gets alarms of the status of each end device to the operators to make corrective actions immediately.

٩

# SOFTWARE SPECIFICATIONS

# **Ethernet Software Features**

Protocols	Modbus TCP Client (Master), Modbus TCP Server (Slave), BACnet IP
	Server and BACnet IP Client
Configuration Options	Web Console (HTTP/HTTPS), Telnet Console
Time Management	NTP Client
Serial Software Features	
Protocols	Modbus RTU/ASCII Master, Modbus RTU/ASCII Slave, BACnet MSTP
	Server, BACnet MSTP Client, BACnet PTP Server and BACnet PTP
	Client
Configuration Options	Serial Console

# HARDWARE SPECIFICATIONS

PMM0408 can be housed in several PMM CPU platforms such as:

- PMM0102 (default platform): PMM Industrial Computer, CPU: Allwinner H3, Quad-core Cortex-A7, DRAM: 512MB RAM and Embedded 8GB eMMC hard drive, Interfaces: 2x Ethernet ,4 x Serial ports.
- PMM0103 (light enclosure): PMM Industrial Computer, CPU: Allwinner H3, Quad-core Cortex-A7, DRAM: 512MB RAM and Embedded 8GB eMMC hard drive, Interfaces: with 3x RS485 Serial ports, and plastic light housing.
- PMM0105: PMM Industrial Computer, CPU: Allwinner H3, Quad-core Cortex-A7, DRAM: 512MB RAM and Embedded 8GB eMMC hard drive, Interfaces: two customizable fiber optic ports and two Serial ports.

The hardware platform is chosen in the order configuration, refer to PMM website for more details about the CPUs <u>https://www.pmm-usa.us/Industrial-Computer.php</u>

# **ORDERING INFORMATION**

م ه

Order Configuration Table							
PMM0408	-X	-09xx	-09xx	-09xx		Table1* Comm port op	otions
1. CPU Platform: PMM0102							
Power supply						<b>COM Ports Option</b>	s
10-56 VDC	-1					Analog input	PMM0901
8-40 VAC	-2					Analog output	PMM0902
36-72 VDC	-3					CANBUS (UART)	<u>PMM0910</u>
25-50 VAC	-4					CANBUS (UART)	<u>PMM0910i</u>
85-285 VAC/100-300 VDC	-5					CANBUS (SPI)	PMM00911
COM Port 1						CANBUS (SPI)	<u>PMM0911i</u>
RS485		-0912				RS485	PMM0912
CAN Bus		-0910				RS422	PMM0913
ANALOG INPUTS		-0901				RS422	PMM0914
DIGTAL INPUT		-0920				RS232	PMM0915
GSM/GPRS		-0917				LTE	PMM0916
See the COM Ports table for more option	5					Digital input	PMM0920
COM Port 2 (Same as COM			-09xx			Digital output	PMM0921
Port 1 options)							
			·				
COM Port 3 (Same as COM				-09xx			
Port 1&2 options)							
COM Port 4 (Same as COM				-09xx			
Port 1&2&3 options)							

## PMM0408

### 2. CPU Platform: PMM0103

Power supply				
10-56 VDC	-1			
COM Port 1				
RS485		-0912		
See the COM Ports table for more options				
COM Port 2 (Same as COM			-09xx	
Port 1 options)				
COM Port 3 (Same as COM				-09xx
Port 1&2 options)				

م ہ

# PMM0408

3. CPU Platform: PMM0105

Power Supply					
10-56 VDC	-1				
8-40 VAC	-2				
36-72 VDC	-3				
25-50 VAC	-4				
85-285 VAC / 100-300 VDC	-5				
COM Port 1		1			
RS485		-0912			
CAN Bus		-0910			
ANALOG INPUTS		-0901			
DIGTAL INPUT		-0920			
GSM/GPRS		-0917			
See the COM Ports table for more op	tions	1			
COM port 2 (Same as			-09xx		
COMport 1 options)					
			·		·
Fiber Optic port 1					
SFP Connector				-SFP0	
Single Mode 20 Km /SC				-SC20	
typeconnector					
Single Mode 40 Km /SC type				-SC40	
Single Mode 80 Km /SC				-5080	
typeconnector				0000	
Fiber Optic port 2 (Same as					-xxxx
Fiber Optic port 1 options)					

# **CONTACT INFORMATION:**

For direct inquiries or any customized orders, contactus on <u>sales@Pmm-usa.us</u>

# **BACnet to MODBUS CONVERTER INTERFACE**

# login

Q

- Type the username "User@Israr.com" and the password "12345678".
- Click on "Login" to login into the system.
- **NOTE:** the username must be lowercase because the web server is case sensitive.

ISRAR	ISRAR ENGINEERING ,LLC
Username	
Password	
	Login

Once the user has logged in successfully the default main web page "General Information" will be displayed as shown in the figure below.

	🗱 😂 😂 General Informations 🔒 🕹 Users Access			
=	Contract Contractions			
	ISRAR			
	Company Name: 	pmm-usaus tttt		and Part and Part of Part of the Part of the Part of the Part of t
	Company Phone:	+962789705508	<b>I</b>	
	Company Address:	Jordan		9.94
	Software licenses:		PMM0103	PMM0107
	license :	PMM All Converters	Industrial Computers - Arm Based Computers	Industrial Computers - 86 Based Computerss
	license Version:	1.0	COMPACT ARM BASED EMBEDDED INDUSTRIAL COMPUTERS	X86 BASED EMBEDDED INDUSTRIAL COMPUTER
			PMM0308 is a rugged powerful rollable fanless Linux based embedded industrial computer, powered by Albulmer H3 CPU, which offers high-performance processing with a high degree of functional integration.	PMM0107 is a ragged powerful reliable fanless industrial embedded computer, powered by Intel <sup>®</sup> Atom <sup>™</sup> x528350 CPU, which offers a high level of performance and low level of power consumption.
¢:				تعادل المراجع (2014-2022) Israr Engineering LLC. All rights reserved. رقام

# Set General Information and Web Page Theme

The "general information" that is displayed at the main page must be set originally by the user. As well as, the user can redesign his own theme style to make the web page more comfortable. **Inserting general information instructions:** 

• Click on "the user's icon" in the right top of the page.

	🗱 😂 General Informations 🕹 Users Access				
	General Informations	1	7		My Account
	ISRAR				admin@israr.com admin@israr.com Sign Out
	ENGINEERING LLC				L My Profile
	Company Name:	pmm-usaus			Change Password
	Company Fmail:				C Restart Application
	company caracteristic		<b>D</b> . ·		U Reboot Device
	Company Phone:	+962/39705508			
	Company Address:	Jorden			
	Software licenses:		PMM0103		
	license :	PMM All Converters	Industrial Computers - Arm Based Computers	Industrial	
	license Version:	1.0	COMPACT ARM BASED EMBEDDED INDUSTRIAL COMPUTERS	X86 BASED	
			PMMMIDIG is a rugged pawerful reliable fanless linux based embedded industrial computer, powered by Allwinner H3 CPU, which offers high performance processing with a high degree of functional integration.	PMM0107 is a r embedded comput which offers a h	
••				©2014-	
10 1				02014-	

• Click on "My Profile" then the web page at which the user can modify the information manually will be displayed as shown below.

BRAR	General Informations 🛛 🍰 Use						
🚨 My Profile							
Settings							
		User		Company		Project	
		Туре	superadmin	Name	pmm-use.us	Name	Petra
		Name	admin@isran.com	Phone	+962789705508	Phone	+962789705508
		Email	admin@israr.com	Email	****	Email	desade
		Phone	+962789705508	Address	Jordan	Address	Jordan
		Startup	Assot Management(Default 🗸 🗸			Location	https://www.google.com/mi
Themes Settings							S B +
Themes Settings				Dana Handar		Contract	3 B +
Themes Settings	Drive	→ Main Header		Page Header		Content	3 B +
Themes Settings Theme Name Menu Position	Drive Top & Left(Default)	<ul> <li>✓ Main Header</li> <li>✓ Background</li> </ul>	· · · ·	Page Header Background	· · · ·	Content Background	<b>S B +</b>
Themes Settings Theme Name Menu Position Logo Type Logo Color	Drive Top & Lett(Default) Icon(Default)	v Main Header v Background v Text	· · · ·	Page Header Background Text	· · · · · ·	Content Background Text	+ a =
Themes Settings Theme Name Menu Position Logo Type Logo Color Foot	Drive Top & Lett(Default) KcolDefault) White	✓ Main Header ✓ Barkground ✓ Inst	· · · ·	Page Header Background Text Border	· · · · · · · · · · · · · · · · · · ·	Content Background Text	0 B +
Themes Settings Theme Name Menu Position Logo Type Logo Color Fost	Drive Top & Lett(Default) kcol/Default) White Calibri	v Main Header v Background v Iost v	· · · ·	Page Header Background Text Border	· · · · · ·	Content Background Text	0 B +
Theme Sattings Theme Name Menu Position Logo Type Logo Color Font	Drive Top & Lett(Default) Kon(Default) White Calibri	Main Header     Background     Toxt     V     Widjets	· · · ·	Page Header Background Text Border Buttons	• • • •	Content Background Text	2 <b>9</b> +
Themes Settings Theme Name Menu Position Logo Type Logo Color Font	Drive Top & Laft(Default) Kcn(Default) White Calibri	Main Header     Background     trat     v     Widjets     Background	•	Page Header Background Text Border Buttons Background	· · · · · ·	Content Background Teat Inputs Background	+ 0 0 v v
Themes Settings Theme Name Menu Position Logo Type Logo Color Fost	Drive Top & Laft[Default] Kc0[Default] White Calibri	Main Header     Background     tost     v      Widjets     Background     sub Background	· · · ·	Page Header Background Trot Border Buttons Background Trot	· · · · · · · · · · · · · · · · · · ·	Content Background Text Inputs Background Text	• • •
Themes Settings Theme Name Menos Position Logo Type Logo Color Fost	Drive Top & Let(Default) Icon(Default) White Calibri	Main Header     Background     inst     Wildjets     Background     Inst     Inst	· · · ·	Page Header Background Iver Border Buttons Background Iver Rafin	· · · · · · · · · · · · · · · · · · ·	Content Background Text Inputs Background Text Border	C B +

- Type the user's name, Email, and phone.
- Select the startup page which will be displayed once the user has logged in to the server.
- **NOTE:** The default startup page is "Assets Management".
- Type the company's name, phone, Email, and address.
- Type the project's name, phone, Email, address, and location.
- After completing inserting all the user's, company's and project's information accurately click on "Save".
- If the information is saved "Updated successfully" will be displayed at the head of the page.
- NOTE: if the information is updated successfully the user will be able to view the general information at the startup page.

Web page theme settings:

- 1) Apply existed theme instructions:
- Select the desired theme from the theme name list.
- Click on "Refresh" to apply the theme.
- 2) Adjust existed theme instructions:
- Edit the chosen theme as wanted.
- Click on "Save".
- If the theme is saved "Updated Successfully" will be displayed at the head of the page.
- **NOTE:** the default theme is not editable.
- 3) Create new theme instructions:
- To add a new theme, click on "Add".
- Name the theme as wanted.
- Select the theme style.
- Click on "Save".
- If the theme is saved "Updated Successfully" will be displayed at the head of the page.
- Select the added theme from the theme name list.
- Click on "Refresh" to apply the theme.

## **Change password**

The user can change the password in order to enhance the security after the first login or any other time as necessary.

#### **Change password instructions:**

- Type the current password.
- Type the new password.
- Retype the new password for confirmation.
- Click on "Change password".
- If the new password is saved "Updated Successfully" will be displayed at the head of the page.

admin@israr.com	com
Current password	ø
New password	ø
Re-type new password	ø
Change Password	

#### To restart the application

• Click on "Restart Application".

#### To reboot the device:

- Click on "Reboot Device".
- The reboot process may take a while.

	My Account	×
,	admin@israr.com admin@israr.com Sign Out	
	L My Profile	
	Change Password	
111	2 Restart Application	
Innn in	U Reboot Device	

# **Overview**

م ه

Overview displays the status of the device and connected devices. Overview consists of three sections:

- 1) Run Time Console: displays the device status, alarms and operational modes.
- 2) system Information: displays system's performance measures as it illustrates the usage and free percentage of:
- CPU.
- CPU.
- RAM.
- Disk.
- 3) System Summary which displays:
- The software version.
- Last Time Started.
- Servers' status which displays the status of Signal-R server and its address, RTU Modbus Slave and TCP Modbus slave, the number of connected TCP clients, number of connections and number of tags.
- Web API status, address, and number of calls.
- Alarms & Events.

Overview				
🖶 RunTime Console			• 2	System Summary
Connected.				Software Version: 1.0.0. Last Time Started: 4/30/2022 12:57:66 PM Servers Status Signal-R Server: Connected Signal-R Address: http://127.0.0.15050
-				RTU Modbus Slave:     • Stopped       TCP Modbus Slave:     • Stopped       TCP Connected Clients:     0       Number of Connections:     6       Number of Tags:     49
System Informations			L.	Web API Status: Connected
CPU	CPU	RAM	DISK	Web API Calls:         961           Web API Address:         http://127.0.0.15005           System Alarms & Events
2.9 GHZ	29 C 11.0%	7.800 GB 7725%	283.000 GB 78.8%	System Total Errors: 7 Ack
Free Used	Tempreture	Free Used	Free Used	



# Monitoring:

The user is able to monitor the status of connections and tags from this page.

• To the auto refresh of the status check the box "Auto Refresh"

### **Connections Monitor:**

- The user must choose the desired connection to display.
- Displays the connections, their status whether **Good**, **Error**, **Idle**, the time and whether the connection is enabled or disabled.

Status	Description
Good	The connection status is good and
	has no problem
Error	There is an error with the connection
	that the user must fix
Idle	The connection is neither connected
	nor has a problem to fix

Connect	on TCPPCUE	NTTest	✓ ■	
Action	Connection	Status	Time	Enabled
No Data Av	eilable Now			

## **Tags/Points Monitor:**

• Displays the connection name (COM1, COM2, COM3 or COM4), the tag name which in the form of (command Slave ID Address), slave ID, address and the read value.

onnection All	✓ Teg	TCPPCUENTIest.Command1	v 🗉 🐓	
ion Tar Name	RawValue	Ordered Value	Value	Slave ID
Command1	0	0	0	

Basic Settings		•	General Servers Config	ration	🖻 🛸 Networ	k Settings			
Server Name	PMMAllConverter		Server Auto Start:	×	Name	Ethernet1	Name	Ethernet2	
Server Location	Amman		Web API Auto Stert:	2	IP Assign	Manual	V IP Ensignment	DHCP	
Time Zone	Amman - 09:31	~	API Port:	5005	IP äxidres	192.168.1.43	IP Address	192.168.2.114	
Local Date	22 / 10 / 04		heading cycle:	1000	Netmask	255.255.255.0	Natimask	255.255.255.0	
Local Time	0 15 : 29 : 50		TCP Port:	502	Gateway	192.168 1.1	Gateway	192.168.2.0/24	
set time to	Server (NTP)	~			DNS Serv	e1 88.00	DNS Server 1	8888	
ntty/i# Address	127.0.0.1				DNS Serv	v2 0.0.0.0	DNS Server 2	4.4.8.8	
					Max Ref.	3	Max Ratry	1	
					Status	Connected	Status	ETHERNET2 NOTFOUND	
Port 1 Neme	COM1		Port 2 Name	COM2	Port 3 Nat	COM3	Port d Nerree	CDM4	
Deud Rate	9600	~	David Rate	9600	V Baud Rete	9600	V Deud Rate	9600	
Parity	None	~	Parity	None	✓ Parity	None	✓ Parky	None	
Data Bits	5	~	Data Bits	в	V Data Bits	5	V Deta Bits	8	
Stop Bits	1	~	Step Bits	1	♥ Stop Bits	4	✓ Stop Bits	1	
Flow Control	None	~	flow control	None	✓ Flow cont	None	✓ How Control	None	
interface	R5-485 2 wire	~	interface	R5-485 2 wire	✓ interface	R5-485 2 w/re	✓ Interface	RS-485 2 wire	
Timeout	3000		Timeout	3000	Timeout	3000	Timeout	3000	
Туре	Master	~	Түрж	Master	түрж	Master	🗸 Турн	Master	
Max Retry	0		Max Retry	0	Max fighty	0	Max Retry	0	
				rang mentioning		turnitable.	STORE OF	tor out the	

### **Basic Settings**

Basic settings display the server's name, location, time zone, local date and time, set time to and NTP/ IP address.

Server Name	PMMAllConverter		
Server Location	Amman		
Time Zone	Amman - 09:31		
Local Date	22 / 10 / 04		
Local Time	<b>0</b> 15 : 29 : 5D		
set time to	Server (NTP)		
NTP/IP Address	127.0.0.1		

• The user can adjust the date. Local time and the time zone based on the server location.

# **General Server Configuration**

Q

erver Auto Start:		
Web API Auto Stert:		
PI Port:	5005	
reading cycle:	1000	
CP Port:	502	

- To enable the server auto start, check the box "server auto start".
- Type the API port.
- Type the reading cycle.
- Type the TCP port.

### **Network Settings**

It is required to insert the settings for each port manually by the user for the TCP ports.

Network Settings				
Name	Ethernet1	Name	Ethernet2	
IP Assignment	Manual	IP Anigrament	DHCP 🗸	
IP Address	192.168.1.43	IP Address	192.168.2.114	
Netmask	255.255.255.0	Netmask	255.255.255.0	
Gateway	192.168.1.1	Gateway	192.168.2.0/24	
DNS Server 1	8.8.0.0	DNS Server 1	8.8.8.8	
DNS Server 2	0.0.0.0	DNS Server 2	4.4.8.8	
Max Retry	3	Max Rutry	1	
Status	Connected	Status	ETHERNET2 NOTFOUND	

- Insert the IP Address, Netmask, Gateway for each port.
- After the user completes inserting the settings for the ports, click on "Save".
- If the settings are saved "Updated Successfully" will be displayed at the head of the page.
- **Solution NOTE:** once the user has set the ports settings the status of each port will be updated.

**Network Settings:** 

م م

Parameter	Value	Notes
Name	Ethernet 1, Ethernet 2	
IP Address	Default IP Address is 192.168.1.240 (Or other 32-bit number)	The IP (Internet Protocol) address identifies the server on the TCP/IP network.
Netmask	255.255.255.0 (Or other 32-bit number)	Netmask identifies the server as belonging to a Class A, B, or C network.
Gateway	192.168.1.1, 192.168.2.1, 192.168.3.1, 192.168.4.1	This is the IP address of the router that provides network access outside the server's LAN.
DNS Server 1	0.0.0.0 (Or other 32-bit number)	This is the IP address of the primary domain name server.
DNS Server 2	0.0.0.0 (Or other 32-bit number)	This is the IP address of the secondary domain name server.
Status	Connected/ disconnected/ not found	Displays the connection status

### **Serial Settings**

Port 1 Name	CD141	
	COMI	
Beud Rate	9600	~
Parity	None	v
Data Bits	5	~
Stop Bits	1	~
Flow Control	None	~
interface	R5-485 2 wire	~
Timeout	3000	
Туре	Master	~
Max Retry	0	
Status	Available	

There are four serial ports the user must set the required parameters for each port.

- Select the Baud Rate ranges from 75 to 128000 bps, Parity, Data Bits, Stop Bits, flow control, interface and type.
- Type the timeout in (ms).
- Click on "Save"
- If the settings are saved "Updated Successfully" will be displayed at the head of the page

**MOTE:** selecting the mode is adjustable only if the user has chosen Modbus gateway mode.

Serial Settings:

Parameter	Value	Notes
Port Name	COM1, COM2, COM3, COM4	
Baud Rate	75, 110, 134, 150, 300, 600, 1200, 1800, 2100, 4800, 7200, 9600, 14400, 19200, 38400, 57600, 115200, 128000 bps	The serial port baud rate on the server must match the serial baud rate of the connected device.
Parity	None, Odd, Even, Mark, Space	This setting must match the data format of the connected device
Data Bits	7,8	This setting must match the data format of the connected device
Stop Bits	1, 1.5, 2	This setting must match the data format of the connected device
Flow control	None, RTS/CTS, RTS Toggle	
Interface	RS-232, RS-422, RS-485 2 wires, RS-485 4 wires	
Timeout	Any inserted value in ms	Timeout field is used to configure how long the gateway will wait for a response from a Modbus ASCII or RTU slave.

# **Protocol Settings**

PMM 0408 consists of meters/controllers acting as Modbus RTU/ASCII/TCP slave/servers and SCADA/DDC acting as a BACnet/IP client/master. Both of these components use distinct protocols, therefore for them to communicate with one another, a gateway is required. When linked to the BACnet/IP master/client, PMM0408 functions as the BACnet/IP server/slave, and when connected to the Modbus RTU/ASCII/TCP slave/server, it functions as the Modbus RTU/ASCII/TCP client/master.

## Modbus TCP Client (Master) Settings

PMM0408 operates as a Modbus client/master in Modbus TCP client/slave mode and actively sends Modbus requests to the Modbus server/slave.

- Choose the type of connection from the drop list "Modbus TCP Client".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

Server Setting:	Connections Settings						
Print         Print <th< th=""><th>Main Connection</th><th></th><th></th><th></th><th></th><th></th><th><b>1 1</b></th></th<>	Main Connection						<b>1 1</b>
Andow row Client         Server Settings         Server Setrettings         Server Settings         Server	ame TCPPCLIENTTwit		Enable Type Modbu	a TCP Client	Port ♥ Bramati	v	
Left digit         Sever String         Sever String <td>Modbus TCP Client</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	Modbus TCP Client						
Interview         Bit Water         Difference         Sold         Sold<	lient Settings			Server Settings			
Na Kary         Same P Adras	Initial delay			(0.30000 mil) TCP Port		502	
Resource Timoch         Optic	Max Retry			(0.5) Server IP Address		0.0.0.0	
Taser     Out     Image: Control of the contro	Response Timeout			(so sector ma) Unit ID		0	
Refinese         000         Image: Control of the cont	Trigger	Gyelic		•			
Coldbas Server-Points         Image:	Poll interval	1000					
Mana Taya Billinahar Addica Order U/W Mudua Wita	the form think						
Action Nume type Bit humber Addres Orient U.W. Widous Write	vioabus server-points	200	8.7 <u>22</u> 289				-0 0
	Action Hume	ryge de recredo	a Hobits	Crow	ψw	madous	Whee

**Client Settings:** 

Paramete <u>r</u>	Value	Notes
Initial delay	0 to 30000 ms	It's possible that some Modbus servers and slaves take longer to boot up than other devices. This could result in the system as a whole experiencing recurrent exceptions during the initial bootup in particular settings. With the Initial Delay setting, you can force PMM0408 to delay delivering the initial request after booting.
Max. retry	0 to 5	This parameter specifies how many times PMM0408 will attempt to communicate with the Modbus server/slave once a Modbus command timeout occurs.
Response timeout	10 to 120000 ms	The time it takes a slave device to reply to a request is determined by the device maker using the Modbus protocol. A Modbus master can be set to wait for a specific period of time for a server/slave response. If no answer is received within the set period, the master will ignore the request and proceed with the action. This enables the Modbus system to continue operating even if a slave device is disconnected or malfunctioning. The Response timeout field on PMM0408 is used to specify how long the gateway will wait for a response from a Modbus server/slave. To manually set the response timeout, consult the manufacturer's documentation for your device.
Trigger	Cyclic Data Change	<b>Cyclic:</b> The command is sent cyclically at the interval specified in the Poll interval parameter. <b>Data change:</b> A command is issued when a change in data is detected.
Poll interval	100 to 1200000 ms	The polling intervals are measured in milliseconds. Because the module transmits each request in turn, the actual polling interval is affected by the number of requests in the queue as well as their parameters. The time span is 100 to 1,200,000 ms.



#### **Server Settings:**

Q 0

- Type the TCP port
- Type server IP address
- Type the unit ID
- After finishing the configuration click on the icon "Save"

To create your Modbus TCP server/slave device:

- Click on the "Add button"
- Configure Slave ID, Device Name, other parameters. Then, the created Modbus device list will be shown under the "Modbus Slave-Points".

After creating a Modbus device, it can be edited by s by double-clicking the device list or pressing the Edit icon.

### Modbus RTU/ASCII Master Settings

In Modbus RTU/ASCII master mode, the PMM0408 acts as a Modbus RTU/ASCII master, actively sending Modbus requests to Modbus RTU/ASCII slaves.

- Choose the type of connection from the drop list "Modbus RTU/ASCII Master".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

Mai connection   main Image: Imag
me jee jee   SPRCUNTER: Image: provide structure     SPRCUNTER:     Medica RTU ASCI Mater     Base Setting     Image: provide structure
Modios RTV ASCI Naster diss Master Setting India data 17.0 V Reports Times A India data passe India Asci Passes Mac Intry a India data Passes India Asci Passes Mac Intry a India data Passes India Asci Passes In
dBas Master Settings Mark 10  V Angenes Treased () () () () () () () () () () () () ()
Made     MU     Magnetes Tremed     Operation       India dansy     India dansy     India dansy     India dansy       Max Naty     India dansy dansy dansy dansy     India dansy     India dansy       India dansy     India dansy da
Inter Amorgania (Inter Amorgania) (Inter Amorgania) (Inter Amorgania) Mati Naty (Inter Amorgania) (Inter Amorgania) (Inter Amorgania) data Slave-Points
Max Nave-Points (parameter treated)
dbu Slave-Points
Achon Neme lype Ed.Namber Address Urder L/W Modbas Write Severi

Modbus Master Settings:

Parameter	Value	Notes
Mode	RTU ASCII	Select the Modbus RTU or Modbus ASCII to communicate with Modbus slave device.
Initial delay	0 to 30000 ms	It's possible that some Modbus servers and slaves take longer to boot up than other devices. This could result in the system as a whole experiencing recurrent exceptions during the initial bootup in particular settings. With the Initial Delay setting, you can force PMM0408 to delay delivering the initial request after booting.
Max. retry	0 to 5	This parameter specifies how many times PMM0408 will attempt to communicate with the Modbus server/slave once a Modbus command timeout occurs.
Response timeout	10 to 120000 ms	The time it takes a slave device to reply to a request is determined by the device maker using the Modbus protocol. A Modbus master can be set to wait for a specific period of time for a server/slave response. If no answer is received within the set period, the master will ignore the request and proceed with the action. This enables the Modbus system to continue operating even if a slave device is disconnected or malfunctioning. The Response timeout field on PMM0408 is used to specify how long the gateway will wait for a response from a Modbus server/slave. To manually set the response timeout, consult the manufacturer's documentation for your device.
Inter-frame delay	10 to 500 ms	For Modbus devices that cannot receive Rx signals within the expected time interval, use this function to determine the timeout interval between characters. If the response timer expires, all received data is lost. If the timeout value is set to 0, PMM0408 will automatically determine the timeout interval.
Inter-character timeout	10 to 500 ms	The time delay for transmitting the data frame received from the slave device to the upstream can be set by the users. If the time interval is set to 0, PMM0408 will determine it automatically.

• After finishing the configuration click on the icon "Save"

To create your Modbus RTU/ASCII slave device:

- Click on the "Add button"
- Configure Slave ID, Device Name, other parameters. Then, the created Modbus device list will be shown under the "Modbus Slave-Points".

After creating a Modbus device, it can be edited by s by double-clicking the device list or pressing the Edit icon.

# **BACnet IP Server Settings**

৫ ৫

- Choose the type of connection from the drop list "BACnet IP Server".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

	BACaset 📌 Overview Mit Mont	toring 🎇 Settings 🛛 About							Help ?
	Connections Settings								
	Se Main Connection								i 2 + B
	Name BACNETIPOIenTest		Enable	Type BACnet IP Server	Po • (	n IOM1	~		
	BACnet IP Server								
	Device Settings								
	Port		(502)						
	Identifier								
	APDU Timeout								
	Num Of Retries								
	Command Parameters								
	Action Description	Identifier	Name	Object	Instance	Pell	Function	Enable	
*									
2									
*									
0								©201	A-2022 PMM. All rights reserved.

Parameter	Notes
Port	
Identifier	Specifies the BACnet ID assigned to the device.
ADPU Timeout	Indicates the amount of time in milliseconds between retransmissions of an APDU requiring acknowledgment for which no acknowledgment has been received.
Num of Retries	Sets the number of times that the driver will retry a request when a response is not received.

www.Pmm-usa.us

# **BACnet IP Client Settings**

- Choose the type of connection from the drop list "BACnet IP Client".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

Connections Settings Main Connection re KCATPOIntes								
Main Connection								
ne KCNETIPOlienflest								
		finable ▼ □	Type BACnet IP Client	v	Port Ethernet 1	~		
BACnet IP Client								
vice Settings								
IP.	127.0.0	1	(122.0.0.1)	Vendor Identifier		1234		
Port	502		(\$22)	Model Name		vl		
Device name	device?			Frimmane Rev		v1.0.0		
Identifier	1			Software Version		v1.0.1		
Vender Name	vendor			APDU Timeout		1000		
				Num Of Retries		3		
ommand Parameters								
Action Description 1	dentifier Name	Object	Instance	Out Of Service	Present Value	Ruliability	Units	Function
🕑 🛅 Test B4Dret IP Client 1	testbenetip	0.Object Analog input	1234	True	0	O:No Fault Detected	0.Square-maters	Read

Parameter	Notes
IP	The IP (Internet Protocol) address identifies the server on the TCP/IP network.
Port	
Device Name	Defines the node's name. The device name must be unique across the entire BACnet network.
Identifier	Specifies the BACnet ID assigned to the device.
Vendor Name	Specifies the name of the OEM.
Vendor Identifier	Specifies the BACnet Vendor ID assigned to the OEM.
Model Name	Specifies the model's name of the OEM's product.
Firmware Rev	Specifies the firmware revision
Software Version	Specifies the software revision
APDU Timeout	Indicates the amount of time in milliseconds between retransmissions of an APDU requiring acknowledgment for which no acknowledgment has been received.
Num of Retries	Sets the number of times that the driver will retry a request when a response is not received.

## **BACnet MSTP Server**

- Choose the type of connection from the drop list "BACnet MSTP Server".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

Ø

	*	BACnet	Convinue	H Monitoring	🗙 Settings	<li>About</li>			
=	¢° Conr	ections Se	ettings						
	Se Mai	n Connecti	on						
	Name							Enable	Туре
	BACNET	1PCIIenTest					v		BACnet MSTP Server
	Se BAC	net MSTP 1	Server						
	Device	Settings							
		dertifier							
		POU Timeou							

९ ४

\* 3 \* 0 
 Non Officing

 Approx
 Non Max
 No
 Non Max
 No
 Pacific
 Radio

Pert ✔ COM1

\*

Parameter	Notes
Identifier	Specifies the BACnet ID assigned to the device.
ADPU Timeout	Indicates the amount of time in milliseconds between retransmissions of an APDU requiring acknowledgment for which no acknowledgment has been received.
Num of Retries	Sets the number of times that the driver will retry a request when a response is not received.

### **BACnet MSTP Client**

- Choose the type of connection from the drop list "BACnet MSTP Client".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

BALand W Overview Mit Monitoring 26 Settings	• About							Hdp
Stale Connection								÷ 7 +
Name		Enable	Туро		fort (			
BACNETIPCIenTest		• 🗆	BACnet MSTP Client	~	COML	~		
BACnet MSTP Client								
Device Settings								
Source Address				Vendor Identifier				
Device name				Model Name				
Identifier				Frimware Rev				
Vander Name				Software Version				
				APDU Timeout				
				Num Of Retries				
Command Parameters								-5 B (
Action Description Identifier	Name	Object	Instance	Out Of Service	Present Value	Rafability	Units	Function

2 0

**i** 2' + 8

Parameter	Notes
Source Address	Specifies the source address
Device Name	Defines the node's name. The device name must be unique across the entire
	BACnet network.
Identifier	Specifies the BACnet ID assigned to the device.
Vendor Name	Specifies the name of the OEM.
Vendor Identifier	Specifies the BACnet Vendor ID assigned to the OEM.
Model Name	Specifies the model's name of the OEM's product.
Firmware Rev	Specifies the firmware revision
Software Version	Specifies the software revision
	Indicates the amount of time in milliseconds between retransmissions of an
APDU Timeout	APDU requiring acknowledgment for which no acknowledgment has been
	received.
Num of Retries	Sets the number of times that the driver will retry a request when a response
Nulli of Nethes	is not received.

### **BACnet PTP Server**

- Choose the type of connection from the drop list "BACnet PTP Server".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

400 J	A seemp Granes						
Connections Settings							
Main Connection							
ame BACNETIPOliunTast		Enstie	Type BACnet PTP Server	Port COM1		~	
BACnet PTP Server							
evice Settings							
APDU Timeout							
Num Of Retries							
ommand Parameters							
Action Description	Identifier	Name	Object	Instance	Poll	Function	Enable

Parameter	Notes
ADPU Timeout	Indicates the amount of time in milliseconds between retransmissions of an APDU requiring acknowledgment for which no acknowledgment has been received.
Num of Retries	Sets the number of times that the driver will retry a request when a response is not received.

### **BACnet PTP Client**

- Choose the type of connection from the drop list "BACnet PTP Client".
- Choose the desired port from the drop list port.
- The following settings will need to be configured as shown below.

	🗱 BACRIEE 🏘 Cherniew Litt Ministoring 🗶 Settings 🔘 About					Help ? 🕚
-	Connections Settings					
	Se Main Connection					10 C2 + D3
	Name BACHET/PCIenTex	€rasi* ▼ □	Type BACnet PTP Client	V COML	~	
	BACnet PTP Client					
	Device Settings					
	Device name			Verdor Identifier		
	Identifier			Model Name		
	Vender Name			Frienware Bey		
				Software Version		
				APDU Timeout		
				Num Of Retries		

Parameter	Notes
Dovice Norma	Defines the node's name. The device name must be unique across the entire
Device Name	BACnet network.
Identifier	Specifies the BACnet ID assigned to the device.
Vendor Name	Specifies the name of the OEM.
Vendor Identifier	Specifies the BACnet Vendor ID assigned to the OEM.
Model Name	Specifies the model's name of the OEM's product.
Firmware Rev	Specifies the firmware revision
Software Version	Specifies the software revision
	Indicates the amount of time in milliseconds between retransmissions of an
APDU Timeout	APDU requiring acknowledgment for which no acknowledgment has been
	received.
Num of Potrios	Sets the number of times that the driver will retry a request when a response
Num of Kethes	is not received.

O

a

0

Logging Time	er	+ 🖬 🖻	🕿 Tags	-a 🕒 🗁 Tag Settings				
lmer	halfsecond	~	Tag Name TagABCDf	Basic Settings			Scaling	
	V	Enabled Zero Based	TagABCDF TagABCDUint TagABCDint16	Logging Setting	s	Enabled	Linner Limit	Enable Scaling Scale to float
nterval	500	(ma)	TagABCDUInt16	Log Timer 1	NON	~	Lower Limit	
belay	0	(ms)	TagABCD1int	Log Timer 2 Log Timer 3	NON	~	Scale X1	
			uint32 TCPPCUENTTest.Command1 BACAUETICELEATER Boothanette				Scale X2 Scale Y1 Scale Y2	

# **Logging Timer**

Logging Tim	her	
Timer	halfsecond	~
	~	Enabled
	~	Zero Based
Interval	500	(ms
Delay	0	(ms

- Click on the add icon "+".
- Type the desired name in "Timer" field.
- Check "Enabled" to enable the timer to save the values in the data base.
- Type the desired interval needed between the readings in (ms).
- Type the desired delay time needed between the readings in (ms).
- Click on "Save".
- Click on "Delete" to delete any not needed timer.

0

6

Basic Settings			Scaling		
		Enabled			Enable Scaling
Logging Setting	s				Scale to float
Log Timor 1			Upper Limit		
rog miller 1	NON		<ul> <li>Lower Limit</li> </ul>		
Log Timer 2	NON		<ul> <li>Scale X1</li> </ul>		
Log Timer 3	NON		<ul> <li>Scale X2</li> </ul>		
			Conto Vil		
			Scale 11		
			Scale Y2		
				Vout = Vin [ ()	(2-Y1) / (X2-X1) ]

### **Basic Settings**

- Check "Enabled" to enable the connection data logging.
- Type the slave ID.
- Choose the data type from the drop list.

Parameter	Value
	Bool
	Bitfield 16
	Bitfield 32
Tupo	Int16
туре	UInt16
	Int32
	UInt32
	Float32

- Type the "Bit Number".
- Type the "Address".
- Choose the tags "Order".

Parameter	Value
	ABCD
	BADC
	CDAB
Order	DCBA
	CDBA
	DCAB

- Choose the swap order from the drop list.
- Choose the Modbus type from the drop list which sets the desired function for the tag.

Parameter	Value		
	F01: Read Coils		
	F02: Read Discrete Input		
MadhucTupa	F03: Read Holding Registers		
woubus rype	F04: Read Input Registers		
	F05: Write Single Coil		
	F06: Write Single Register		



#### **Logging Settings**

- The user can choose up to three log timers for logging the tags in.
- Choose the log timers needed from the drop lists.

#### Scaling

- To enable the scaling function for the logged values, check the box "Enable scaling".
- To scale to float, check the box "Scale to float".
- Set the upper and lower limits.
- **MOTE:** the upper and lower limits values shall only be a number, 0 or NON.
- Set the scaling values: X1, X2, Y1, Y2.

Scaling values conditions:

- 1) X2 ≠X1 && X2 > X1
- 2) Y2 ≠Y1 && Y2 > Y1

The scaling equation:

- V<sub>out</sub>=V<sub>in</sub> ((Y2-Y1) /(X2-X1))
- Click on "Save" to save the tags settings.
- All the tags along with their settings will be displayed in "Tags"

## About

About Page consists of three sections:

- 1) General Information: Displays general information about the Modbus converter server including:
- Model Name.
- Serial Number.
- Software Version.
- Firmware Version.
- Hardware Base.
- Hardware Version.

**MOTE:** general information is set by the manufacturer and it is not editable.

- 2) Project settings & Firmware:
- Click on "Backup" to create project settings backup.
- Click on "Restore" to restore a previously created project setting.

**NOTE:** Same instructions are applicable for Firmware as the user can create firmware backup or restore a previously created firmware.

- Alarms & Events Log: The user may adjust the duration of keeping logs, download logs and delete logs.
   Adjust Keeping Alarms & Events Log Duration Instructions:
- Type the number of days you want to keep the logs for in the specified field and check the box to enable the setting.
- Click on "Save".
- Download Alarms & Events Log Instructions:
- Choose the required alarms & events log based on the day and date from the drop list.
- Click on "Download".

#### **Delete Alarms & Events Log Instructions:**

- Choose the required alarms & events log based on the day and date from the drop list.
- Click on "Delete".

E General Information     E Project Strings & Firmware     E Annu Se Events Log       Model Rever     Settings :     Interview       Software Version     FirmWare :     Settings :       Note Name     Reverse Version     Settings :	
Model Nome     Setting :     Marenting       Setting :     Books     Becks       Software Version     FmWVer :     Books       Revenue Nave     Books     Revenue       Becksore Nave     Booksore     Revenue	
Sviid Ru.     Roue     Roue     Select Columnic       Suthaar Version     PretWare:     Teachear Select Columnic     Select Columnic       Ruchear Saw     Roue     Roue     Mage Select Columnic       Ruchear Saw     Roue     Roue     Roue	
Software Version     FemWare :     FemWare :     FemWare :     Maint Columns       Reviewer Nano     Reviewer Nano     Reviewer Nano     Maint Columns       Reviewer Nano     Reviewer Nano     Register :     Register :       Reviewer Nano     Reviewer Nano     Reviewer Nano     Register :       Reviewer Nano     Reviewer Nano     Reviewer Nano     Register :       Reviewer Nano     Reviewer Nano     Reviewer Nano	
Finance basis     Points     Description       Machiner basis     Inclusion     Machiner basis     Machiner basis       Tochware basis     Inclusion     Inclusion     Machiner basis       Basis     Inclusion     Inclusion     Machiner basis       Basis     Inclusion     Inclusion     Inclusion       Basis     Inclusion     Inclusion     Inclusion       Basis     Inclusion     Inclusion     Inclusion	
Nacharan Nau         Inclusion         Inclusion	
Tarbeau Vision         portionates           D Developed By         En Licensed To	
Developed By	
E Developed By ELicensed To	
POWER METER MONITOR         POWER METER MONITOR         Bissa Northänt 157h street, wirk 1214         Northänt 157h street, wirk 214         Northänt 157h street, wirk 214         WWW.PMM-USA.US	.C Suite 503
📚 License Status:	۶ 🕫
Hardware ID	
This Mashina ID	

# Sign Out

٩ ه

After completing settings configuration, the user signs out of the system.

- Click on "Admin".
- Click on "Sign out" then the log in window will be displayed.

